


WEEK 4

Configure DHCP within a LAN and outside

LAN. OBSERVATION:



Procedure :-

- * Connect 3 PCs & 1 server to a switch using copper.
- Storage through cable
- * Click on server & go to Services tab select DHCP & Turn on the DHCP service.
- * Set the IP address as the start IP address as: and click the same button. 10.0.0.2.
- * Before this, set the IP address of server in config tab under fast Ethernet as 10.0.0.1
- * Next click on PC & go to desktop tab, here click on IP configuration. Select DHCP here. It will request for an IP address & successfully get the DHCP request also sets the IP address.
- * Repeat this steps for other 2 PCs
- * To send a packet across PCs, go to PC's command prompt & type ping destination IP address.

PING output

Packet traces PC command line 1.0.

PC > Ping 10.0.0.3

pinging 10.0.0.3 with 32 bytes of data.

Reply from 10.0.0.3 : bytes=32 time=0ms TTL=128

Reply from 10.0.0.3 : bytes=32 time=0ms TTL=128,

Reply from 10.0.0.3 : bytes=32 time=1ms TTL=128

Reply from 10.0.0.3 : bytes=32 time=0ms TTL=128

Ping statistics for 10.0.0.3

Packets: Sent = 4, Received = 4, Lost = 0, (0% loss)

Approximate round trip times in milliseconds:

minimum = 0ms, maximum = 1ms, average = 0ms

Observation

- * DHCP is used to dynamically assign an IP address to any device or node.
- * It is a client-server protocol in which servers manage a pool of unique IP addresses & also about client configuration parameters.
- * DHCP-enabled clients sends a request to DHCP server when they want to connect to a network.
- * The DHCP server responds to the client request by providing IP configuration information from address pools, previously specified by a network administrator.


N
Z
3/16/2023

13-7-23

Program 4.2

Aim :- Configure DHCP within a LAN & outside LAN

Topology



Procedure :- * Add a router, a switch & 2 PC's to 4.1 program network & connect the router to both switches.

- * Set the server IP address of Server and with the help of Server set the first 3 PC's IP address through DHCP.
- * Now set the router IP address with the following commands statically.

Step 1: NO

Step 2: Enable

Step 3: Config T

Step 4: Interface fastEthernet 4/0

Step 5: IP address 10.0.0.20 255.0.0.0

- Step 6: No shot
- Step 7: Exit
- Step 8: Interface fastEthernet 0/0
- Step 9: IP address 20.0.0.20 255.0.0.0.
- Step 10: No shot
- Step 11: Exit
- Step 12: Exit
- Step 13: Show IP route

- * Go to server & set the gateway as 10.0.0.20
- * Again go to router CLI & follow these command
 - Step 14: Config +
 - Step 15: interface fastEthernet 0/0
 - Step 16: IP helper-address 10.0.0.1
 - Step 17: No shot
 - Step 18: Exit
- * Now, go to server services & add one more pool as server pool 1, start IP address as 20.0.0.2 & default gateway as 20.0.0.20. Then click add & save.
- * Now set the other 2 pc's IP address by going to Desktop → IP configuration & selecting DHCP which will automatically generate its IP address.
- * Now the network is complete & can send packets from any PC to other by typing ping destination IP address in their respective command prompts.

PING output

Packet tracer PC command line 1,0

PC > Ping 20.0.0.2

Pinging 20.0.0.2 with 32 bytes of data.

(Request timed out).

Reply from 20.0.0.2 : bytes=32 time=0ms TTL=127
Reply from 20.0.0.2 : bytes=32 time=0ms TTL=127
Reply from 20.0.0.2 : bytes=32 time=0ms TTL=127

Ping statistics for 20.0.0.2

Packets Sent = 4, Received = 3, Lost = 1 (25% Loss)

Approximate round trip times in milliseconds

minimum = 0ms, maximum = 0ms Average = 0ms.

Observation:


- * DHCP is used to assign IP addresses dynamically to different devices.
- * To assign continuous IP address we create a server pool where we assign the starting IP address & a default gateway number. For PCs under different switches we create a different server pool again & start.

This task is done by the router to deliver the packets to correct destination IP address & also send back the ACK into the original device.


N
8/8/2023

TOPOLOGY:

PROGRAM 4.1:




PROGRAM 4.2:



OUTPUT:

PROGRAM 4.1:



```
PC0
Physical Config Desktop Custom Interface

Command Prompt X


Packet Tracer PC Command Line 1.0
PC>ping 10.0.0.3

Pinging 10.0.0.3 with 32 bytes of data:

Reply from 10.0.0.3: bytes=32 time=0ms TTL=128
Reply from 10.0.0.3: bytes=32 time=0ms TTL=128
Reply from 10.0.0.3: bytes=32 time=1ms TTL=128
Reply from 10.0.0.3: bytes=32 time=0ms TTL=128

Ping statistics for 10.0.0.3:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 1ms, Average = 0ms

PC>
```



PROGRAM 4.2:

PC0

Physical Config Desktop Custom Interface

Command Prompt

```

Packet Tracer PC Command Line 1.0
PC>ping 20.0.0.2

Pinging 20.0.0.2 with 32 bytes of data:

Request timed out.
Reply from 20.0.0.2: bytes=32 time=0ms TTL=127
Reply from 20.0.0.2: bytes=32 time=0ms TTL=127
Reply from 20.0.0.2: bytes=32 time=0ms TTL=127

Ping statistics for 20.0.0.2:
  Packets: Sent = 4, Received = 3, Lost = 1 (25% loss),
Approximate round trip times in milli-seconds:
    Minimum = 0ms, Maximum = 0ms, Average = 0ms

PC>ping 20.0.0.3

Pinging 20.0.0.3 with 32 bytes of data:

Request timed out.
Reply from 20.0.0.3: bytes=32 time=0ms TTL=127
Reply from 20.0.0.3: bytes=32 time=0ms TTL=127
Reply from 20.0.0.3: bytes=32 time=0ms TTL=127

Ping statistics for 20.0.0.3:
  Packets: Sent = 4, Received = 3, Lost = 1 (25% loss),
Approximate round trip times in milli-seconds:
    Minimum = 0ms, Maximum = 0ms, Average = 0ms

PC>

```

