

WEEK 5

Configure Web Server, DNS within a

LAN. OBSERVATION:

201-23 Lab -5 (i)

DNS
Aim: Configuring DNS server with LAN

Topology:-

The diagram illustrates a simple network topology. At the top center is a rectangular box labeled "Switch PT". Two lines extend downwards from it to two separate boxes below. The left box is labeled "PC-PT" and the right box is labeled "Server-PT".

Procedure :


- 1) Create a topology as shown above.
- 2) Configure the PC with IP address & gateway and subnet mask.
- 3) Add DNS as 10.0.0.2 to the PC & the IP address as 10.0.0.1 and gateway 10.0.0.2.
- 4) Click on Server & click on Services → HTTP & HTTPS click on 'ON' then select the DNS click on 'on' and add Name : test.com Address : 10.0.0.2
- 5) Now go to config → FastEthernet - IP address 10.0.0.2 Subnet mask 255.0.0.0
- 6) Now go to settings in the config gateway - 10.0.0.2 DNS server 10.0.0.2.
- 7) Now go to PC click on desktop → web browser & type the 'test.com' in URL & click on go.
- 8) You will see the html index that has written in the HTTPS button.

Observation

DNS is the Domain name system. DNS is linked to the internet & focused on a system using Internet Protocol (IP). DNS servers are required for the working of DNS. The IP address is calculated with the aid of a lookup table.
→ PC communicated with the server using the IP address as well as using the Domain

N.D
31/8/2023

TOPOLOGY:



OUTPUT:

